

## Index

Page references for Part A have the prefix 'Part A' (e.g. aquatic invertebrates, Part A[2-11]), references for Part B have no prefixes (e.g. afflux at bridges and other structures, 22-10), and references for appendices are denoted with an 'A' (e.g. backwater calculation, A-10).

### A

- Afflux at bridges and other structures, 22-10
- Aggressive groundwater, 14-5
- Air entrainment, 22-14 to 22-15
- Appearance of waterway structures, 13-5
- Approved materials web site, 14-4
- Aquatic invertebrates, Part A[2-11], 3-3, 3-6 to 3-9
  - feeding preferences, 3-7 to 3-9
  - habitat preferences, 3-7 to 3-9
  - insect pests, 18-3 to 18-4
- Aquatic plants—*see* aquatic vegetation
- Aquatic vegetation, 2-10 to 2-11, 8-7, 9-17 to 9-18, 19-5
  - loss, 2-10
  - maintenance, 2-10 to 2-11, 8-7, 9-17 to 9-18, 19-5
  - planting, 9-17
  - proliferation, 2-11
- Areal reduction factor, 21-9

### B

- Backwater calculation, A-8 to A-9
- Bank materials, 9-14 to 9-15
- Bank profile, 9-12 to 9-13
- Bank protection—*see* bank stabilisation
- Bank regrading, 12-6
- Bank stabilisation, 7-7 to 7-9, 9-14 to 9-15, 12-6 to 12-9
- Bank vegetation, 9-16—*see also* riparian vegetation
- Base flow, 2-5
- Basins—*see* detention basins; soakage basins
- Bed shear stress and the stable bed, 9-6, 22-10 to 22-12
- Bend losses at channel bends, 22-8
- Bend losses in culverts and pipes, 22-14
- Biosecurity, 11-8 to 11-10
- Birds, 3-11 to 3-18, 10-6
  - habitat preferences table, 3-14 to 3-15
  - restoring habitat, 3-12 to 3-17, 10-6
- Blackflies, 18-3, 19-5
- Boulders and cobbles, 9-14
- Bridges, 13-3 to 13-7
  - appearance, 13-4 to 13-5
  - hydraulic design criteria, 13-6 to 13-7
  - safety, 13-6
  - consents, 17-4 to 17-6, 20-7
- Building next to waterways, 12-9
- Building consents, 17-8, 20-6 to 20-7

### C

- Cables, ducts and service pipes, 9-19, 13-5
- Canterbury mudfish, 3-6, 3-10, 10-6
- Channel bed stabilisation, 12-5 to 12-6

- Channel cross-section, 9-11 to 9-13
- Channel meandering, 9-6 to 9-7
- Channel of composite roughness, 22-4
- Channel stabilisation, 7-7 to 7-10, 12-5 to 12-6, 22-10 to 22-12
- Channel widths and depths, 9-11 to 9-12
- Checklist
  - design of treatment systems, 6-42
  - operation and maintenance, 19-4 to 19-5
  - site assessment, Part A[3-8]
- Christchurch Drainage Board, 4-8, 8-3, 14-3, A-2
- Climate change, 20-3 to 20-4, A-2
- Coefficient of runoff, 21-6 to 21-8
- Community involvement, Part A[4-1 to 4-12]
- Computer software for water surface profiles, 22-8
- Consent process, 17-1 to 17-8
- Consents, 9-10, 17-1 to 17-8, 20-6 to 20-7
  - building, 17-8, 20-6 to 20-7
  - City Council, 17-4 to 17-8
  - Environment Canterbury, 17-4 to 17-5
- Consultation, Part A[4-7 to 4-12]
- Constructed wetlands, 6-30 to 6-38, 6-40 to 6-42
  - design, 6-32 to 6-37
  - monitoring, 6-41 to 6-42
  - operation and maintenance, 6-38, 6-40
  - types, 6-31 to 6-32
- Contaminants, 2-8 to 2-9, 6-4
- Culture, Part A[2-18 to 2-22, 3-23 to 3-24], 10-10
- Culverts, 13-3 to 13-12, 22-12 to 22-15
  - appearance, 13-4 to 13-5
  - hydraulic design, 13-6 to 13-7, 22-12 to 22-15
  - pipe bend losses, 22-14
  - providing fish access, 13-8 to 13-10
  - safety, 13-6, 13-11 to 13-12
- Cutoff channels—*see* hillside interception channels

### D

- Darcy-Weisbach formula, 22-3
- Daylighting, 14-3
- Debris separation, 13-12, 14-8, 14-10—*see also* litter interception
- Definitions and useful numbers, A-2 to A-3
- Design storm duration, 21-3 to 21-6
- Detention basins, 6-24 to 6-29, 6-35 to 6-37
  - design considerations, 6-26 to 6-29
  - operation and maintenance, 6-38 to 6-39
- Detention wet ponds
  - monitoring, 6-41 to 6-42
- Double ring infiltrometer, 6-18
- Double ring infiltrometer test procedure, A-10 to A-11
- Drainage
  - groundwater, 5-6 to 5-10
  - natural processes, Part A[2-23]
  - roadside, 5-3 to 5-5
- Drawing standards, A-6
- Dry basins—*see* detention basins

**E**

Ecological zone planting, 11-5 to 11-6  
 Ecology  
   general, Part A[2-9]  
   developing visions, Part A[3-13 to 3-14]  
 Entrance loss coefficients, 22-13  
 Erosion processes, 2-6, 4-7 to 4-8, 12-3 to 12-4  
 Erosion protection, 7-7 to 7-9, 12-5 to 12-9, 9-14 to 9-15  
   at outfalls, 14-13  
   stable bed velocities, 22-11  
 Essential public services— inundation criteria, 20-7

**F**

Fences, waterway, 13-19  
 Field drains— *see* subsoil drains  
 Filling next to waterways, 12-9  
 Financial comparison of costs, A-4 to A-5  
 First flush interception, 6-13  
 First flush volume determination, 6-14  
 Fish, 2-11, 3-3 to 3-7, 3-10, 10-6, 11-4 to 11-5  
   barriers to access, 2-11  
   feeding preferences, 3-10  
   habitat preferences, 3-4 to 3-7, 3-10, 10-6, 11-4 to 11-5  
 Fish access  
   barriers to, 2-11  
   culvert and weir design, 13-8 to 13-10  
   floodgates, 13-15  
   ford design, 13-11  
 Flap valves, 13-14 to 13-5  
 Flood level table, A-3  
 Floodgates— fish access, 13-15  
 Floodgates and flap valves, 13-14 to 13-5  
 Flooding— level of risk, 20-4  
 Floodplain management, 20-3 to 20-4  
 Floodplain area, 9-13  
 Fords, 13-11  
 Free overfalls, 22-16  
 Freeboard, 13-6, 20-4  
 Froude number, 9-8, 22-6, 22-12

**G**

Geomorphology, 4-3 to 4-6  
 Geomorphology and hydrology, 4-1 to 4-11  
 Geotextiles, 12-5 to 12-6, 14-5  
 Grill design criteria, 13-11 to 13-13  
 Ground soakage and permeability field testing, A-10 to A-12  
 Groundwater drainage, 5-6 to 5-10

**H**

Habitat fragmentation, 2-11  
 Habitat preferences  
   birds, 3-14 to 3-15, 10-6  
   fish, 3-5 to 3-7, 3-10, 10-6, 11-5  
   invertebrates, 3-7 to 3-9, 3-18  
   plants, 10-5 to 10-6  
 Head loss— change in alignment, 22-8

Head loss— change in cross-section, 22-8  
 Heritage, Part A[2-16, 3-21 to 3-22]  
 Hill waterways, 7-1 to 7-11, 13-7  
   bridge design, 13-7  
   secondary flow paths, 20-5  
   stabilisation, 7-7 to 7-9  
 Hillside interception channels, 5-5, 20-7  
 Hillside trenchline scour, 14-6  
 Hillside pipes, 14-5  
 Hydraulics, 22-1 to 22-17, A-19  
 Hydraulic capacity of restored waterways, 9-5  
 Hydrology— advanced analysis, 21-8 to 21-11  
 Hydrology and geomorphology, 4-9  
 Hyetographs, 21-8 to 21-10

**I**

Impacts of development  
   on geomorphology and hydrology, 4-9  
   on soils, 4-7 to 4-8, 12-4  
   on waterways and wetlands, 2-1 to 2-15  
 Inanga, 3-5, 3-10, 11-5  
 Inlet structures, 14-9 to 14-10  
 Insect pests, 18-1 to 18-6, 19-5  
 Insects— *see* invertebrates  
 Instream communities, 3-3 to 3-11  
   monitoring, 3-11  
 Inundation design criteria, 20-6 to 20-7  
 Inundation design performance standards, 20-1 to 20-7  
 Inundation design philosophy, 20-4  
 Inverse augerhole method, 6-18, A-11  
 Invertebrates— *see also* aquatic invertebrates  
   aquatic, Part A[2-11], 3-3, 3-6 to 3-9  
   terrestrial, Part A[2-11], 3-18

**K**

Kerb and channel, 5-5

**L**

Land tenure identification, Part A[3-3]  
 Landscape, Part A[2-12, 3-15 to 3-17]  
 Level datum, A-2  
 Lifelines considerations, 19-4  
   pump stations, 13-16 to 13-17  
 Lined drain flow nomograph, A-15  
 Litter interception, 6-9, 14-8— *see also* debris separation  
 Loess deposition and erosion characteristics, 7-5  
 Logs and stumps, 9-15  
 Lowland waterways  
   categories, 8-4 to 8-5  
   maintenance, 8-7  
   restoration, 8-5 to 8-7, 9-1 to 9-19  
   length of, 8-3

**M**

Macro pollutant traps, 6-8 to 6-9  
 Macrophytes— *see* aquatic vegetation

Maintenance—*see also* operation and maintenance  
 aquatic plants, 2-10 to 2-11, 8-7, 9-18  
 constructed wetlands, 6-38, 6-40  
 detention basins, 6-38 to 6-39  
 floodgates, 13-15  
 lowland waterways, 8-7  
 ponds, 9-10  
 riparian planting, 11-10 to 11-11  
 rivers, 8-7  
 soakage systems, 6-38 to 6-39

Manholes, 14-7

Manning formula, 22-3

Manning's roughness coefficient, 22-3 to 22-5

Manning's roughness coefficient table, 22-5

Marginal vegetation—*see* riparian vegetation

Meandering the channel, 9-6 to 9-7

Midges, 18-3, 19-5

Minimum floor level, 20-6

Monitoring  
 constructed wetlands, 6-41 to 6-42  
 detention basins, 6-41 to 6-42  
 instream communities, 3-11  
 overview, Part A[3-34]  
 soakage systems, 6-40 to 6-41

Mosquitoes, 18-3 to 18-6, 19-5

Mudfish, 3-6, 3-10, 10-6

## N

Native birds, 3-11

Natural asset management—overview, Part A[1-2]

Natural asset management strategy—Port Hills, 7-4

Non uniform flow, 22-6 to 22-7

## O

Operation and maintenance—*see also* maintenance  
 constructed wetlands, 6-38, 6-42  
 detention basins, 6-38 to 6-39  
 overview, Part A[3-33], 19-1 to 19-5  
 soakage systems, 6-38 to 6-39

Operation and maintenance checklist  
 all systems, 19-3 to 19-5  
 stormwater treatment, 6-42

Ordering plants, 11-6

Outfall erosion protection, 14-13

Outfall pipes, 9-18, 14-10 to 14-12

Outfall water levels, 22-9 to 22-10

Outfalls to rivers and larger waterways, 22-9 to 22-10

Overflow soakage chambers, 6-22

## P

Part full pipe flow A-16

Partners and stakeholders, Part A[1-6]

Permeability testing, 6-17 to 6-18, A-10 to A-12

Permitted activities, 17-4

Pest management strategy, 11-8 to 11-10

Philosophy, Part A[1-2]

Pipe bedding and haunching, 14-5

Pipe cover, 14-4

Pipe flow nomograph, A-18

Pipes  
 hydraulic design, 22-12 to 22-15  
 inlet structures, 14-9 to 14-10  
 laying, 14-5 to 14-6  
 longitudinal gradients, 14-6  
 outfall structures, 14-10 to 14-12  
 selection, 14-4 to 14-5  
 stability, 14-13  
 termination details, 14-11 to 14-12  
 alignment and minimum size, 14-3 to 14-4

Pipeline backwater calculation, A-8 to A-9

Pipeline gradients, 14-6, 14-7

Pipeline structures, 14-1 to 14-3

Plant establishment and on-going maintenance, 11-10 to 11-11, 19-5

Plant ordering, 11-6

Plant pests, 11-8 to 11-10

Planting  
 aquatic vegetation, 9-17 to 9-18  
 for bank and channel stabilisation, 7-8 to 7-9  
 for birds, 3-12 to 3-16  
 for terrestrial invertebrates, 3-18  
 hill waterways, 7-8 to 7-10  
 marginal, 9-16, 11-4 to 11-5, 15-5  
 planning, design and preparation, 11-3 to 11-7  
 riparian, 9-5, 11-1 to 11-12, 15-5  
 wetlands, 10-5 to 10-6

Planting times, 11-6

Plants—*see* vegetation

Point estimate rainfall, 21-9

Ponds, Part A[2-6], 9-7 to 9-10

Pools, 9-7 to 9-10

Port Hills natural asset management strategy, 7-4

Port Hills values, 7-3

Pressure pipelines, 14-6

Private flat land—inundation criteria, 20-6

Private hill land—inundation criteria, 20-6

Probability of a flood event table, 20-4

Protection mechanisms, Part A[3-31]

Public access, 10-10, 16-1 to 16-5

Public reserves—inundation criteria, 20-6

Public roads and road reserves—inundation criteria, 20-6

Public safety, 15-1 to 15-5

Pumping stations, 13-15 to 13-18

## R

Rainfall and runoff, 21-1 to 21-11

Rainfall hyetographs, 21-8 to 21-10

Rainfall intensity, 21-6, A-17

Rainfall maps, 21-8

Rainfall/runoff loss rates, 21-10 to 21-11

Rational method  
 standard method, 21-3  
 two-value method, 21-7 to 21-8

Recreation, Part A[2-14], 10-10

Resource consents, 17-1 to 17-8  
 City Council, 17-4 to 17-8

- Environment Canterbury, 17-4 to 17-5
- Resource consents and permitted activities, 17-4
- Resource Management Act, 13-7, 17-1 to 17-8, 20-5 to 20-6
- Restoration, determining the extent of, 9-4
- Restoring bird habitat, 3-12 to 3-17, 10-6
- Restoring waterway form, 9-1 to 9-20
- Restoring wetlands, 10-1 to 10-10
- Retaining walls, 12-7 to 12-9
- Riffle run pool design, 22-12
- Riffle run pool sequences, 9-7 to 9-8
- Riffles, 9-7 to 9-8
- Riparian buffer widths, 9-16, 11-3
- Riparian habitats and corridors, 3-17
- Riparian planting, 11-1 to 11-12—*see also* planting
- Riparian vegetation
  - benefits, 9-16
  - effect on flow, 9-13, 22-4
  - loss of, 2-11
  - planting, 9-16, 11-1 to 11-12, 15-5—*see also* planting
- Risk of flooding, 20-4
- Rivers—*see also* waterways
  - definition, 8-4, 13-7
  - length, 8-3
  - maintenance, 8-7
- RMA—*see* Resource Management Act
- Roadside drainage, 5-3 to 5-5
- Roofwater soakage, 6-15, 6-17
- Runoff coefficient, 21-6 to 21-8
- Runs, 9-7 to 9-8
- Rural land use, 2-12 to 2-13
- Rural waterways, 8-6
  - hydraulics, 6-19
  - monitoring, 6-40 to 6-41
  - operation and maintenance, 6-38 to 6-39
  - site investigations, 6-17 to 6-18
  - types, 6-15 to 6-16
- Soakage test, A-10 to A-12
- Soakage, roofwater, 6-15, 6-17
- Soil erosion, 4-7 to 4-8
- Soil infiltration characteristics, 6-17 to 6-18
- Soil permeability, 6-17 to 6-18, A-10 to A-12
- Soils, 4-1 to 4-11
  - for restoration, 4-10
  - for urban planning, 4-9
  - general, 4-3 to 4-6
  - impacts of development, 4-7 to 4-9
  - importance, 4-9
  - minimising impacts, 4-8
- Springs, Part A[3-17], 5-6, 9-4
- Stabilisation
  - bank, 7-7 to 7-9, 9-14 to 9-15, 12-6 to 12-9
  - channel, 7-7 to 7-9, 12-5 to 12-6, 22-10 to 22-12
- Stable bed velocity table, 22-11
- Stakeholder and partner identification, Part A[3-4]
- Stakeholders, Part A[1-2]
- Statutory framework, Part A[1-3 to 1-4]
- Stopbanks, 13-18
- Storm design profile, 21-9 to 21-10
- Stormwater catchment, typical, A-8
- Stormwater contaminants, 2-6 to 2-9, 6-4
- Stormwater outfalls, 9-18, 14-10 to 14-13
- Stormwater pipelines, 14-3 to 14-6
- Stormwater treatment systems, 6-1 to 6-44
- Stormwater treatment systems
  - design checklist, 6-42
  - selection, 6-5
  - types, 6-6 to 6-9
- Streams—*see* waterways
- Stream bank materials, 9-14 to 9-15
- Streambed substrate, 9-15 to 9-16
- Strickler's formula, 22-11
- Structures on private property—*inundation* criteria, 20-6 to 20-7
- Stumps, 9-15
- Subcritical flow, 22-6
- Subsoil drains, 5-7 to 5-10
- Substrate
  - in waterways, 9-15 to 9-16
  - in wetlands, 10-8
- Sumps, 14-8 to 14-9, 22-15 to 22-16
  - capacity, 22-16
  - spacing, 14-9
  - collection of water from side channels, 22-15 to 22-16
- Sumps as features, 14-9
- Supercritical flow, 22-6
- Surface water interception, 5-1 to 5-10
- Sustainable management, Part A[1-1 to 1-6]
- Swales, 5-4 to 5-5, 6-6 to 6-7, 6-15 to 6-16

**T**

Terrestrial invertebrates, Part A[2-11], 3-18  
 insect pests, 18-1 to 18-6  
 Thrust blocks, 14-6  
 Tidal levels, A-2 to A-3  
 Tidal outfall design water levels, 22-9  
 Tidal outfalls, 22-9 to 22-10  
 Time of concentration, 21-3  
 Time of entry, 21-4  
 Time of network flow, 21-5  
 Traffic loading HN-HO-72, A-7  
 Treatment system selection, 6-5  
 Treatment system types, 6-6 to 6-9  
 Tree stumps, 9-15

**U**

Uniform flow resistance formulae, 22-3

**V**

Vegetated swales—*see* swales  
 Vegetation—effect on flow, 22-4  
 Vegetation, aquatic—*see* aquatic vegetation  
 Vegetation maintenance practices, 2-10 to 2-11  
 Vegetation, terrestrial—*see* bank vegetation; riparian  
 vegetation; planting  
 Velocity limits for bed stability, 22-10 to 22-12  
 Visions, developing, Part A[3-11 to 3-26]

**W**

Water quality, 2-6 to 2-9, 6-4  
 Water races, 8-7 to 8-8  
 Water surface profiles, 22-6 to 22-8  
 Waterstops, 14-5  
 Waterway bank protection—*see* bank stabilisation  
 Waterway categories, 8-4 to 8-5  
 Waterway erosion protection, 7-7 to 7-9, 12-5 to 12-9,  
 9-14 to 9-15  
 Waterway fences, 13-19  
 Waterway hydraulic capacity, 9-5  
 Waterway longitudinal channel profile, 9-5  
 Waterway restoration, 9-1 to 9-20  
 Waterway restoration issues, 8-5 to 8-7  
 Waterway setback, 8-4, 13-18, 17-5, 20-3  
 Waterway structural lining, 12-6 to 12-9  
 Waterway structures, 13-1 to 13-20  
 Waterways,  
 hill, 7-1 to 7-11  
 lowland, 8-1 to 8-8  
 rural, 8-6  
 secondary flow paths, 20-4 to 20-5  
 Weeds/plant pests, 11-8 to 11-10  
 Weirs—providing fish access, 13-8 to 13-10  
 Weirs and free overfalls, 22-16  
 Wetland birds, 3-12 to 3-16  
 Wetland restoration, 10-1 to 10-10

Wetlands, 2-14 to 2-15, 6-5, 6-30 to 6-39, 10-1 to 10-10  
 impacts of development, 2-14  
 management, 10-8 to 10-10  
 restoration, 10-1 to 10-10  
 types, 10-3 to 10-5  
 Wetlands, basins and ponds—overview, Part[A 2-6]  
 Wetlands, constructed—*see* constructed wetlands  
 Whitebait—*see* inanga  
 Wildlife corridors, 3-17

